IMSA CABLE 19-1, #14 AWG, 2 CONDUCTOR

PEDESTRIAN PUSH BUTTON STATION	
BASIC COLOR	SIGNAL INDICATION
BLACK	PUSH BUTTON
WHITE	PUSH BUTTON COMMON

IMSA CABLE 19-1, #14 AWG, 4 CONDUCTOR

SIGNAL HEADS	
BASIC COLOR	SIGNAL INDICATION
RED	RED
BLACK	YELLOW
GREEN	GREEN
WHITE	VEH. COMMON

PEDESTRIAN HEADS	
BASIC COLOR	SIGNAL INDICATION
RED	DON'T WALK
GREEN	WALK
WHITE	PED. COMMON
BLACK	SPARE

IMSA CABLE 19-1, #14 AWG, 7 CONDUCTOR

SIGNAL HEADS		
BASIC COLOR	SIGNAL INDICATION	HAWK HEAD
RED	RED	RED 1
BLACK	YELLOW	RED 2
GREEN	GREEN	
ORANGE	YELLOW ARROW	YELLOW
BLUE	GREEN ARROW	
WHITE	VEH. COMMON	COMMON
BLACK/WHITE	SPARE	

NOTES:

1. FOR MATERIAL AND INSTALLATION SPECIFICATIONS SEE MCDOT SUPPLEMENT SECTION 478.
2. FOR EACH PEDESTRIAN PUSH BUTTON ONE (1) 2-CONDUCTOR CABLE SHALL BE PULLED CONTINUOUSLY FROM THE CONTROL CABINET TO THE PUSH BUTTON STATION.

MARICOPA COUNTY DEPARTMENT OF TRANSPORTATION STANDARD DETAIL	COLOR CODE - 2, 4 AND 7 CONDUCTOR CABLE	DATE: 7/01/2013	DETAIL NO. 4799-1